




**TENT COMPONENTS**

- A - 8 Base & Roof Poles
- B - 4 Top Wall Poles
- C - 4 Bottom Wall Poles
- D - 8 Corner Connectors
- E - 2 Roof Cross Poles
- F - 2 Roof Cross Poles
- G - 1 Tent Floor & Wall Skin
- H - 3 Port Covers
- I - 1 Floor Liner
- J - 1 Roof Skin




The **Silverback grow tent** is AgroMax's most innovative grow tent yet. With an innovative "diamond pattern" reflective liner for **ULTIMATE** light spread, ultra-high ceilings, a green tent skin, and custom leaf zippers, this tent sets the bar for grow tents.


**Please Note:**

- B & C poles interlock together as shown below (Fig. A)
- Metal corners should be attached as shown below (Fig. B)
- Port covers attach over the three lower access ports and has three options: **Fully Cover**, **Mesh Vent Cover**, and **Off**.
- Please be patient and gentle while pulling the tent skin over the frame to avoid any tearing seams

**Figure A**



**Figure B**



1. Depress chrome nipples and insert male connectors into female receiver slots.
2. Allow chrome nipples to lock into place through female connectors.

**NEW AgroMax LINER PATTERN**



**MORE FEATURES**



- 1 Assemble the frame as noted above
- 2 Unzip the skin (G) and set frame into the bottom of the tent skin
- 3 Drape the roof skin (J) over the top of the frame
- 4 Begin to pull the skin up around the sides of the frame
- 5 Zip the walls to the top and bottom of the skin and insert floor liner
- 6 Your tent is now ready for lighting, ventilation, and plants