



AgroMax EXTRA LARGE GROW TENT INSTRUCTIONS





ASSEMBLE POLES AS SHOWN BELOW TO COMPLETE FRAME.




A = EIGHT 46.75"
 B = SIX 38.75"
 C = SIX 38.75"
 D = SIX 52"
 E = FOUR 55"
 F = FOUR 49.5"
 G = FOUR 4 WAYS
 H = EIGHT CORNERS

CONNECTIONS




NOTES: * B & C POLES ATTACH TOGETHER AS SHOWN IN FIGURE A
 * CORNERS AND 3 WAYS ATTACH AS SHOWN IN FIGURE B
 * VENT PORT COVERS ATTACH OVER VENT PORT HOLES



UNZIP TENT SKIN AND SET FRAME INTO BOTTOM OF TENT SKIN



PULL TENT SKIN OVER FRAME AND ZIP UP SIDES



LAY TENT FLOOR LINER IN PLACE AND TIE TO TENT CORNERS



ZIP UP DOOR PANELS. YOUR TENT IS NOW READY FOR LIGHTING, VENTILATION AND PLANTS