

# 240 Volt Digital Timer

# Instructions for Operation

The 240 Volt digital timer will display the current time when operating. It will control up to twenty (20) separate timing programs. There are many combinations of timing programs available to the customer. Such as: hourly, daily or weekly settings. Keep Apollo<sup>®</sup> 11 – 240 Volt digital timer away from spray and pesticides.

## To set the current day and time:

- 1. Hold 'SET' for three seconds.
- 2. Navigate to the correct day with the arrow buttons.
- 3. Press 'SET', adjust the hour with the arrow buttons.
- 4. Press 'SET', adjust the minute with the arrow buttons.
- 5. Press 'SET' again to finalize the day and time adjustments.
- 6. If day or time is set incorrectly, repeat this process.

NOTE: the Apollo<sup>®</sup> 11 uses 24 hour (military) time as its default display mode. Hold 'TIME' for three(3) seconds when the current time is displayed to toggle between 24 hour and 12 hour time modes.

## To program On/Off cycles on Apollo® 11:

- Press the right arrow (⇒) button until 'PROG' is displayed and '1 ON' is blinking. '1 ON' indicates that you are programming the start day and time of the first timed cycle.
- 2. Press 'SET', adjust ON operation days with the arrow buttons.
- 3. Press 'SET', adjust the starting hour with the arrow buttons.
- 4. Press 'SET', adjust the starting minute with the arrow buttons.
- Press 'SET', then press the right arrow (
  button. '1 OFF' will begin blinking, indicating that you are adjusting the end day and time

of the first timed cycle. Repeat steps 3 & 4 to program 'OFF' time.

Continue this process for up to 20 separate ON/ OFF cycles, which will display as '2 ON', '2 OFF', '3 ON', '3 OFF', etc. By pressing the 'MANUAL' button at any point during the setting process will cancel the currently selected set time. Press the right arrow ( $rac{r}$ ) button at the main screen to review your set schedules and select them for adjustment.

#### Timer Switch mode:

Press 'MANUAL' to scroll through 'AUTO OFF', 'ON', AUTO ON' and 'OFF' modes.

#### Countdown mode:

Press the 'CTD' button to use the countdown function, which counts down from a user-determined length of time before powering attached devices. Press 'TIME' + left arrow ( ) at the same time to enter the Countdown (CTD) mode function. Then press 'SET' and set HOUR, MIN-UTE and SECOND of countdown. Press 'CTD' to start countdown process. The countdown function has a maximum time length of 23 hours, 59 minutes and 59 seconds.

#### Random mode:

Press the 'RND' button when the timer is set to 'AUTO' mode. 'RND' will appear on the right side of the display. This randomly extends 'ON' and 'OFF' cycles for attached 240 Volt appliances from 2 to 30 minutes, which can be used as a theft deterrent when the area is unattended.

#### **Reset function:**

Press the 'RESET' button to default to factory settings.

NOTE: if not functioning properly, plug in for 5 minutes and press the reset button. This generally fixes any problems you may encounter.

10 Amps/240 Volts/60 Hz.

Do not exceed 1000 Watts ballast rating

1 year warranty